


HUSKY BOY

FX TYPE: Boost


Based on the Paul Cochrane Fat Bastard™

© 2016 madbeanpedals



- Note the jumper -

2" W x 2" H



Etcher's Paradise projects are intended for DIY use only! Commercial pedal manufacturing using these materials is strictly forbidden.

B.O.M.					
Resistors		Caps		Diodes	
R1	2M2	C1	100n	D1	1N5817
R2	1M	C2	1uF	Transistors	
R3	10k	C3	33n	Q1 - Q3	J201
R4	1k	C4	1uF	Pots	
R5	100R	C5	1uF	VOL	100kA
R6	1k	C6	10n	BASS	25kB
R7	10M	C7	10uF	TREB	100kB
R8	100R	C8	100uF	GAIN	10kB
R9	4k7	C9	100n		
R10	10k	C10	10uF		
R11	10k				

Shopping List				
Value	QTY	Type	Rating	
100R	2	Metal/Carbon Film	1/4W	
1k	2	Metal/Carbon Film	1/4W	
4k7	1	Metal/Carbon Film	1/4W	
10k	3	Metal/Carbon Film	1/4W	
1M	1	Metal/Carbon Film	1/4W	
2M2	1	Metal/Carbon Film	1/4W	
10M	1	Metal/Carbon Film	1/4W	
10n	1	Film	16v. Min	
100n	2	Film	16v. Min	
33n	1	Film	16v. Min	
1uF	3	Film	16v. Min	
10uF	2	Electrolytic	16v. Min	
100uF	1	Electrolytic	16v. Min	
1N5817	1			
J201	3			
100kA	1	PCB Right Angle	16mm	
25kB	1	PCB Right Angle	16mm	
100kB	1	PCB Right Angle	16mm	
10kB	1	PCB Right Angle	16mm	

1590B Drill Guide

4.43"W x 6.46"H

