

**FX TYPE: Bass Fuzz, Octaver**Based on the Maestro® Brassmaster™

Enclosure Size: 125B

"Softie" compatibility: Softie1, Softie3

© 2020 madbeanpedals



### Overview

The Brassmaster had a short production life (around 3-4 years) way back in the 70's. It's one of those pedals that has passed into some kind of mythology because of its rareness. But, there are good reasons to warrant the hype. It delivers that special kind of "highly compressed wall of fuzz" that you can really dig into. And, those units seem to go for four figures nowadays. Build one for 1/50th the price!

The **BoomBoom** is a 95% Brassmaster. It uses a more widely available transformer than the vintage unit (but similar spec) and it adds an output volume control.

### **Controls**


- BASS Sets the volume of clean bass sent to the output.
- SENSE Sets the input volume to the octaver/EQ circuit.
- BRASS Set the output volume of the octaver/EQ circuit.
- VOL The total mixed output from the BASS, SENSE and BRASS controls.
- **HARM** In the left position, this switch adds some extra octave up signal in parallel with the EQ circuit. In the right position, it sends the full octave up directly to the EQ.
- **BRASS1/2** This switch toggles between two EQ settings. The left position is mids-focused and the right position is mids-scooped.

See the Notes section for a little more info on using the controls.


**Terms of Use:** You are free to use purchased **BoomBoom** circuit boards for both DIY and small commercial operations. You may not offer **BoomBoom** PCBs for resale or as part of a "kit" in a commercial fashion. Peer to peer re-sale is fine, though.

**Technical assistance** for your build(s) is available via the <u>madbeanpedals forum</u>. Please go there rather than emailing me for assistance on <u>builds</u>. This is because (1) I'm not always available to respond via email in a timely and continuous manner, and (2) posting technical problems and solutions in the forum creates a record from which other members may benefit.


Parts BoomBoom



Values BoomBoom



Traces BoomBoom



B.O.M. BoomBoom

Resistors		Ca	aps	Diodes		
R1	1M5	C1	100n	D1	1n914	
R2	150k	C2	100n	D2	1n914	
R3	150k	C3	1uF	D3	1n914	
R4	390R	C4	1uF	D4	1n914	
R5	12k	C5	1uF	D5	1N5817	
R6	10k	C6	100n	Transistors		
R7	470k	C7	47n	Q1	2N3392	
R8	470R	C8	1uF	Q2	2N3392	
R9	10k	C9	1uF	Q3	2N3392	
R10	4k7	C10	10n	Q4	2N3392	
R11	1M5	C11	100n	Q5	2N3392	
R12	150R	C12	10n	Q6	2N3392	
R13	12k	C13	4n7	Q7	2N5308	
R14	2k2	C14	4n7	Transfo	ormer	
R15	2k2	C15	47n	XFM1	42TM018	
R16	82k	C16	100uF	Switc	hes	
R17	220k	C17	100n	HARM	SPDT	
R18	220k	C18	47uF	BRASS1/2	3PDT	
R19	2k2			Po	ts	
R20	10k			BASS	10kB	
R21	22k			BRASS	10kB	
R22	3k3			SENSE	10kB	
R23	6k8			VOL	100kA	
R24	47k					
R25	6k8					
R26	47k					
R27	1M5					
R28	1k					
R29	47k					
R30	150k					
R31	4k7					
R32	820R					
rs2	OZUK					

Shopping List BoomBoom

Values	QTY	Туре	Rating
150R	1	Metal / Carbon Film	1/4W
390R	1	Metal / Carbon Film	1/4W
470R	1	Metal / Carbon Film	1/4W
820R	1	Metal / Carbon Film	1/4W
1k	1	Metal / Carbon Film	1/4W
2k2	3	Metal / Carbon Film	1/4W
3k3	1	Metal / Carbon Film	1/4W
4k7	2	Metal / Carbon Film	1/4W
6k8	2	Metal / Carbon Film	1/4W
10k	3	Metal / Carbon Film	1/4W
12k	2	Metal / Carbon Film	1/4W
22k	1	Metal / Carbon Film	1/4W
47k	3	Metal / Carbon Film	1/4W
82k	1	Metal / Carbon Film	1/4W
150k	3	Metal / Carbon Film	1/4W
220k	2	Metal / Carbon Film	1/4W
470k	1	Metal / Carbon Film	1/4W
1M5	3	Metal / Carbon Film	1/4W
4n7	2	Film	16v min.
10n	2	Film	16v min.
47n	2	Film	16v min.
100n	5	Film	16v min.
1uF	5	Electrolytic	16v min.
47uF	1	Electrolytic	16v min.
100uF	1	Electrolytic	16v min.
1n914	4		
1N5817	1		
2N3392	6	NPN	
2N5308	1	NPN	
42TM018	1	10KCT-10KCT	
SPDT	1	On/On, Solder Lug	
3PDT	1	On/On, Solder Lug	
10kB	3	PCB Right Angle	16mm
100kA	1	PCB Right Angle	16mm
		_	

Parts Guide BoomBoom

#### 2n3392:

http://smallbear-electronics.mybigcommerce.com/transistor-2n3392/

### 2n5308:

http://smallbear-electronics.mybigcommerce.com/transistor-2n5308/

#### 42TM018:

https://www.mouser.com/ProductDetail/42TM018-RC/

# SPDT (On/On):

http://smallbear-electronics.mybigcommerce.com/dpdt-on-on-solder-term/

# 3PDT (On/On):

http://smallbear-electronics.mybigcommerce.com/3pdt-on-on/

# 16mm PCB Right Angle Pots (10kB, 100kA):

<u>smallbear-electronics.mybigcommerce.com/alpha-single-gang-16mm-right-angle-pc-mount/</u>

## Thinline DC Jack:

http://smallbear-electronics.mybigcommerce.com/dc-power-jack-all-plastic-unswitched-2-1-mm/

## **Enclosed Mono:**

http://smallbear-electronics.mybigcommerce.com/1-4-in-mono-enclosed-jack/ http://smallbear-electronics.mybigcommerce.com/1-4-in-mono-enclosed-switchcraft-111x/

# **Lumberg Mono:**


http://smallbear-electronics.mybigcommerce.com/lumberg-1-4-compact-shrouded-mono-jack/

Notes BoomBoom

 The best way to understand how the four potentiometer controls work is to simply think of them as volume or mix controls. IOW, what you get at the output is due to a combination of mixed signal levels.


- To get output at the BRASS pot, you'll need to have some signal going in from the SENSE pot.
  The more SENSE you have, the more aggressive the BRASS control will be. To add some extra
  bottom end, turn up the cleans with the BASS control. And, so on. The added VOL pot makes
  balancing these mixed signals easier, IMO, and seems to be a popular mod for DIY versions of
  this circuit.
- Use the Build Pic (2nd to last page) to see the transistor orientation. The 2n3392 are kind of neat with their oval, smooth packaging.
- Make sure you put in the 3PDT toggle the correct way! The switch goes left to right, not up and down.
- Make sure you put the transformer in the right way, too! The PCB has labels for Primary and Secondary (P and S).

Wiring Diagram BoomBoom



125B Drill Guide BoomBoom

Note: Drill Guides are approximate and may require tweaking depending on the types of jacks, switches and pots you use.



• If you prefer soft touch relay bypass, the mbp Softie1 or upcoming Softie3 should fit in this enclosure. The Softie2 will not. You'll need to work out a different LED location if you use either of those.

**Voltages BoomBoom** 

		_		 	
Q1	2n3392	Q4	2n3392	Q7	2n5308
В	0.77	В	0.64	В	0.95
С	2.05	С	4.7	С	7.4
Ε	193mV	Ε	55mV	Ε	33mV
Q2	2n3392	Q5	2n3392		
В	0.85	В	4.7		
С	2.5	С	5.2		
Ε	260mV	Е	4		
Q3	2n3392	Q6	2n3392		
В	2.5	В	1.94		
С	8	С	9.17		
Ε	1.9	Е	1.35		

- 9.42vDC One SpotCurrent Draw: ~5mA

Build Pic BoomBoom

